


REPLACEMENT

HINT:

- The installation is in the reverse order of the removal. However, when there is a special point concerning the installation, it is indicated.
 - On the RH side, use the same procedures as on the LH side.
1. REMOVE DECK BOARD SUB-ASSY (See page 76-42)
 2. REMOVE DECK BOARD ASSY (See page 76-42)
 3. REMOVE REAR FLOOR MAT SUPPORT PLATE REAR (See page 76-42)
 4. REMOVE DECK FLOOR BOX RH (See page 76-42)
 5. REMOVE DECK TRIM COVER REAR (See page 76-42)
 6. REMOVE DECK TRIM SIDE BOARD UPR RH (See page 76-42)
 7. REMOVE SIDE TRIM BOX ASSY RH (See page 76-42)
 8. REMOVE DECK TRIM SIDE PANEL ASSY RH (See page 76-42)
 9. REMOVE ROOF SIDE GARNISH ASSY INNER RH (See page 76-42)
 10. REMOVE REAR DOOR SCUFF PLATE RH (See page 76-42)
 11. REMOVE REAR DOOR SCUFF PLATE LH (See page 76-42)
 12. REMOVE REAR DOOR WEATHERSTRIP RH
 13. REMOVE DECK BOARD ASSY (See page 76-42)
 14. REMOVE BACK DOOR WEATHERSTRIP
 15. REMOVE DECK TRIM COVER REAR (See page 76-42)
 16. REMOVE REAR SEAT CUSHION ASSY AND REAR SEAT BACK ASSY (See page 72-20)
 17. REMOVE DECK TRIM SIDE PANEL ASSY RH (See page 76-42)
 18. REMOVE REAR SEAT 3 POINT TYPE BELT ASSY OUTER
 - (a) Remove the bolt and disconnect the belt assy on the shoulder anchor side.
 19. REMOVE REAR SEAT BELT ASSY OUTER CENTER
 - (a) Remove the rear seatback board RH (See page 72-20).
 - (b) Remove the rear seat shoulder belt cover (See page 72-20).
 - (c) Remove the bolt and nut rear seat belt assy outer center.
 20. REMOVE REAR SEAT INNER W/CENTER BELT ASSY LH
 - (a) Remove the bolt and the belt assy.




21. INSTALL REAR SEAT BELT ASSY OUTER CENTER

- (a) Install the belt assy with the bolt and nut.
Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)
- (b) Install the rear seat shoulder belt cover (See page 72-20).
- (c) Install the rear seatback board RH (See page 72-20).
- (d) Check the degree of tilt when the belt begins to lock the ELR.
 - (1) Check the belt does not lock within 15° of tilt in all the direction but the belt locks over 45° of tilt, when moving the installed retractor gently.
 If operation is not as specified, replace the belt assy.
- (e) Install the assy with the bolt.
Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)

(f) Check the ELR lock.

NOTICE:

The check should be performed with the assembly installed.



22. INSTALL REAR SEAT 3 POINT TYPE BELT ASSY INNER

(a) Install the floor anchor and belt assy with the bolt, as shown in the illustration.

Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)

NOTICE:

Do not make the anchor part run onto the protrusion part of the floor panel.

(1) Check that the belt locks when pulling out the belt quickly with the belt installed.

If operation is not as specified, replace the rear seat belt assy outer center.

(b) Check the fastening function of the child restraint system.


NOTICE:

The check should be performed with the assembly installed.

(1) Check that the belt cannot be pulled out any more but can be rewound after the belt is fully pulled out.

(2) Check that the belt can be pulled out and rewound after the belt is fully rewound.

If operation is not as specified, replace the rear seat belt assy outer center.




23. INSTALL REAR SEAT INNER W/CENTER BELT ASSY LH

(a) Install the belt assy with the bolt as shown in the illustration.

Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)

NOTICE:

- Do not make the anchor part run onto the protrusion part of the floor panel.
- Do not disassemble the retractor.



24. INSTALL REAR SEAT 3 POINT TYPE BELT ASSY OUTER

NOTICE:

Do not disassemble the retractor.

(a) Check the degree of tilt when the belt begins to lock the ELR.

(1) Check that the belt does not lock within 15° of tilt in all the direction but the belt locks over 45° of tilt, when moving the installed retractor gently.

If operation is not as specified, replace the belt assy.

- (b) Install the belt assey on the retractor side with the bolt.
Torque:
8.5 N·m (87 kgf·cm, 75 in·lbf) for upper bolt
42 N·m (430 kgf·cm, 31 ft·lbf) for lower bolt
- (c) Install the center pillar garnish upper RH (See page [76-42](#)).
- (d) Install the center pillar garnish lower RH (See page [76-42](#)).
- (e) Install the belt assy outer on the floor anchor side with the bolt.
Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)
- (f) Check the ELR lock.

NOTICE:

The check should be performed with the assembly installed.

- (1) Check that the belt locks when pulling out the belt quickly with the belt installed.

If operation is not as specified, replace the belt assy outer.

- (g) Check the fastening function of the child restraint system.

NOTICE:

The check should be performed with the assembly installed.

- (1) Check that the belt cannot be pulled out any more but can be rewound after the belt is fully pulled out.
- (2) Check that the belt can be pulled out and rewound after the belt is fully rewound.

If the operation is not as specified, replace the belt assy.

25. INSTALL REAR SEAT CUSHION ASSY AND REAR SEAT BACK ASSY (See page [72-20](#))