


<b>DTC</b>	<b>11</b>	<b>ROOM TEMPERATURE SENSOR CIRCUIT</b>
------------	-----------	--

**CIRCUIT DESCRIPTION**

This sensor detects the temperature inside the cabin and sends appropriate signals to the A/C amplifier.


DTC No.	Detection item	Trouble Area
11	Open or short in room temperature sensor circuit	<ul style="list-style-type: none"> <li>• Cooler thermistor (Room temperature sensor)</li> <li>• Harness or connector between cooler thermistor (room temperature sensor) and A/C amplifier</li> <li>• A/C amplifier</li> </ul>

**WIRING DIAGRAM**



## INSPECTION PROCEDURE

## 1 INSPECT AIR CONDITIONING AMPLIFIER(TR, SG)



- (a) Remove the A/C amplifier with the connectors being connected.
- (b) Turn ignition switch to ON.
- (c) Measure voltage between terminal TR and SG of the A/C amplifier connector at each temperature.

**Voltage:**

at 25 °C (77 °F) : 1.8 - 2.2 V

at 40 °C (104 °F) : 1.2 - 1.6 V

**HINT:**


As the temperature increases, the voltage decreases.

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION  
SHOWN ON PROBLEM SYMPTOMS TABLE**

**NG**

**2 INSPECT COOLER THERMISTOR**



- (a) Remove the cooler thermistor (room temp. sensor).
- (b) Measure resistance between terminals of the cooler thermistor (Room temp. sensor) connector at each temperature.


**Resistance:**

**at 25 °C (77 °F): 1.65 - 1.75 kΩ**

**at 40 °C (104 °F): 0.55 - 0.65 kΩ**

**HINT:**

As the temperature increases, the resistance decreases, as shown in the illustration.



**NG** **REPLACE COOLER THERMISTOR**

**OK**

**3 CHECK HARNESS AND CONNECTOR(BETWEEN COOLER THERMISTOR (ROOM TEMP. SENSOR) AND AIR CONDITIONING AMPLIFIER)**

- (a) Check for open and short circuit in the harness and the connector between the cooler thermistor (room temp. sensor) and the A/C amplifier (See page [01-35](#)).

**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****4 CHECK DIAGNOSTIC TROUBLE CODE**

- (a) Start up the DTC check mode.  
(b) Check that DTC 11 is not output again.  
**Standard: DTC 11 is not output.**

**OK****SYSTEM OK****NG****CHECK AND REPLACE AIR CONDITIONING AMPLIFIER**