



REPLACEMENT

1. PRECAUTION(See page 60-1)
2. DISCONNECT BATTERY NEGATIVE TERMINAL
3. PLACE FRONT WHEELS FACING STRAIGHT AHEAD
4. REMOVE STEERING WHEEL COVER LOWER NO.2
5. REMOVE STEERING WHEEL COVER LOWER NO.3
6. REMOVE HORN BUTTON ASSY
7. REMOVE STEERING WHEEL ASSY(See page 50-8)
SST 09950-50013 (09951-05010, 09952-05010, 09953-05020, 09954-05021)
8. REMOVE STEERING COLUMN COVER LWR
9. REMOVE STEERING COLUMN COVER UPR




10. DISCONNECT PASSENGER AIRBAG CONNECTOR

11. REMOVE INSTRUMENT PANEL SAFETY PAD SUB-ASSY
12. REMOVE DEFROSTER NOZZLE ASSY
13. REMOVE HEATER TO REGISTER DUCT NO.2



14. REMOVE INSTR PNL PASS L/DOOR AIR BAG ASSY
 - (a) Remove the 2 screws.



- (b) Release the rear side wall of the airbag door from the hook by slightly deflecting it and roll the instr pnl pass l/door airbag assy forward.
 - (c) Release the front side wall of the airbag door from the other hook and remove the instr pnl pass l/door airbag assy.

15. INSPECT INSTR PNL PASS L/DOOR AIR BAG ASSY(See page 60-8)
16. INSTALL INSTR PNL PASS L/DOOR AIR BAG ASSY
17. INSTALL INSTRUMENT PANEL SAFETY PAD SUB-ASSY
18. CENTER SPIRAL CABLE(See page 60-23)
19. INSTALL STEERING WHEEL ASSY(See page 50-8)
20. INSPECT STEERING WHEEL CENTER POINT
21. INSTALL HORN BUTTON ASSY(See page 60-14)
22. INSPECT HORN BUTTON ASSY(See page 60-14)
23. INSPECT SRS WARNING LIGHT(See page 05-614)