


# CHARCOAL CANISTER ASSY (1GR-FE)

## REPLACEMENT

1208K-01

### 1. REMOVE SPARE TIRE



### 2. REMOVE CHARCOAL CANISTER ASSY

- (a) Disconnect the fuel tank vent hose from the charcoal canister.
  - (1) Deeply push the connector inside.
  - (2) Pinch portion A.
  - (3) Pull out the connector.
- (b) Disconnect the canister outlet hose No. 2 from the charcoal canister.
  - (1) Deeply push the connector inside.
  - (2) Pinch portion A.
  - (3) Pull out the connector.
- (c) Disconnect the VSV connector from the CCV.
- (d) Disconnect the purge line hose from the charcoal canister.
- (e) Remove the 3 bolts and the charcoal canister from the body.

### 3. INSTALL CHARCOAL CANISTER ASSY

- (a) Install the charcoal canister with the 3 bolts.  
**Torque: 20 N·m (204 kgf·cm, 15 ft·lbf)**
- (b) Connect the purge line hose to the charcoal canister.
- (c) Connect the VSV connector to the CCV.
- (d) Connect the canister outlet hose No. 2 to the charcoal canister.
- (e) Connect the fuel tank hose to the charcoal canister.