

BACK MONITOR SYSTEM DOES NOT DISPLAY IMAGES WHEN THE SHIFT LEVER IS IN R RANGE

INSPECTION PROCEDURE

1 INSPECT PARK/NEUTRAL POSITION SWITCH ASSY

(a) Check the park/neutral position switch ASSY (See page [05-464](#)).

NG

REPLACE PARK/NEUTRAL POSITION SWITCH ASSY(See page [40-3](#))

OK

2 INSPECT RADIO RECEIVER ASSY

(a) Check the radio receiver ASSY (See page [05-1043](#)).

NG

REPLACE RADIO RECEIVER ASSY
(See page [67-6](#))

OK

3 INSPECT TELEVISION CAMERA ASSY

(a) Check the television camera ASSY (See page [05-1043](#)).

NG

REPLACE TELEVISION CAMERA ASSY
(See page [67-18](#))

OK

4 INSPECT BACK MONITOR CAMERA WIRE

(a) Check the back monitor camera wire (See page [05-1043](#)).

NG

REPLACE BACK MONITOR CAMERA WIRE
(See page [67-16](#))

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR(See page [01-35](#))