


# FRONT AXLE LH HUB BOLT REPLACEMENT

300F6-01


## 1. REMOVE FRONT WHEEL



## 2. REMOVE FRONT DISC BRAKE CALIPER ASSY LH


- (a) Using SST, disconnect the brake tube from the disc brake caliper assy.  
SST 09023-00100
- (b) Remove the 2 bolts and disc brake caliper assy.

## 3. REMOVE FRONT DISC



## 4. REMOVE FRONT AXLE LH HUB BOLT


- (a) Using SST and a screwdriver, remove the hub bolt.  
SST 09611-12010



## 5. INSTALL FRONT AXLE LH HUB BOLT

- (a) Pass a new hub bolt through the axle hub.
- (b) Pass a washer plate, as shown in the illustration, through the hub bolt, and install the hub bolt as tightening the hub nut.

## 6. INSTALL FRONT DISC



- 7. INSTALL FRONT DISC BRAKE CALIPER ASSY LH**
- (a) Install the disc brake caliper assy with the 2 bolts.  
**Torque: 123 N·m (1,254 kgf·cm, 91 ft·lbf)**
  - (b) Using SST, connect the brake tube to the disc brake caliper assy.  
SST 09023-00100  
**Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)**

- 8. BLEED BRAKE LINE (See page 32-4 )**
- 9. CHECK FLUID LEVEL IN RESERVOIR (See page 32-4 )**
- 10. CHECK BRAKE FLUID LEAKAGE (See page 32-4 )**
- 11. INSTALL FRONT WHEEL**  
**Torque: 112 N·m (1,142 kgf·cm, 83 ft·lbf)**