


## TC TERMINAL CIRCUIT

### CIRCUIT DESCRIPTION

DTC output mode is set by connecting terminals TC and CG of the DLC3.  
The DTCs are displayed by blinking the SRS warning light.

### WIRING DIAGRAM




#### HINT:

When each warning light stays blinking, a ground short in the wiring of terminal TC of the DLC3 or an internal ground short in each ECU is suspected.


## INSPECTION PROCEDURE

## 1 CHECK WIRE HARNESS (DLC3 - AIRBAG SENSOR ASSY CENTER)

DLC3:



Airbag Sensor Assy Center:

H40173  
H40065

H43360

- Turn the ignition switch to the LOCK position.
- Disconnect the airbag sensor assy center connector.
- Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection       | Condition | Specified condition |
|-------------------------|-----------|---------------------|
| DLC3 (TC) - A32-19 (TC) | Always    | Below 1 $\Omega$    |


NG

**REPAIR OR REPLACE WIRE HARNESS (TC of DLC3 - TC of AIRBAG SENSOR ASSY CENTER)**

OK

## 2 CHECK WIRE HARNESS (CG of DLC3 - BODY GROUND)

DLC3



H40173

- Measure the resistance according to the value(s) in the table below.


**Standard:**

| Tester connection       | Condition | Specified condition |
|-------------------------|-----------|---------------------|
| DLC3 (CG) - Body ground | Always    | Below 1 $\Omega$    |

NG

**REPAIR OR REPLACE WIRE HARNESS (CG of DLC3 - BODY GROUND)**

OK

**3 CHECK WIRE HARNESS (TC of AIRBAG SENSOR ASSY CENTER - BODY GROUND)**

- (a) Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection         | Condition | Specified condition |
|---------------------------|-----------|---------------------|
| A32-19 (TC) - Body ground | Always    | 1 MΩ or Higher      |

**NG****REPAIR OR REPLACE WIRE HARNESS AND EACH ECU****OK****REPLACE AIR BAG SENSOR ASSY CENTER**