


## REPLACEMENT

1. PRECAUTION(See page 60-1 )
2. DISCONNECT BATTERY NEGATIVE TERMINAL(See page 60-1 )
3. REMOVE SEAT TRACK BRACKET COVER OUTER FRONT LH(See page 72-10 )
4. REMOVE SEAT TRACK BRACKET COVER INNER FRONT LH(See page 72-10 )
5. REMOVE SEAT TRACK OUTER COVER LH(See page 72-10 )
6. REMOVE SEAT TRACK BRACKET COVER INNER LH(See page 72-10 )
7. REMOVE FRONT SEAT ASSY LH(See page 72-10 )



8. REMOVE SEAT POSITION AIR BAG SENSOR
  - (a) Disconnect the connector of the seat position airbag sensor.
  - (b) Remove the bolt and seat position airbag sensor.

### 9. INSTALL SEAT POSITION AIR BAG SENSOR

- (a) Install the seat position airbag sensor with a new bolt.

**Part No.:**

**Bolt: 90119-06871**

**Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)**

- (b) Connect the connector of the seat position sensor.

#### NOTICE:

- Installation of the connector is done with the sensor assembly installed. Make sure the sensor assembly is installed with the specified torque.
  - If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
  - When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
  - After installation, shake the sensor assembly to check that there is no looseness.
10. INSTALL FRONT SEAT ASSY LH(See page 72-10 )  
Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)
  11. SRS WARNING LIGHT(See page 05-614 )