

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Horn does not sound	1. Horn button switch	-
	2. High pitched horn	69-3
	3. Low pitched horn	69-3
	4. HORN relay	69-3
	5. Wire harness	-