



## REPLACEMENT



### 1. REMOVE REAR LATERAL CONTROL ROD ASSY


- (a) Remove the bolt.



- (b) Remove the bolt, nut and lateral control rod assy.


HINT:

While fixing the nut, turn and remove the bolt.




### 2. INSTALL REAR LATERAL CONTROL ROD ASSY

- (a) Install the lateral control rod assy with the bolt.



- (b) Install the bolt and the nut.

### 3. STABILIZE SUSPENSION (See page 27-3)



#### 4. FULLY TIGHTEN REAR LATERAL CONTROL ROD ASSY

(a) Fully tighten the 2 bolts.

**Torque: 130 N·m (1,326 kgf·cm, 96 ft·lbf)**

HINT:

While fixing the nut, turn and install the bolt.