

<b>DTC</b>	<b>P0335</b>	<b>CRANKSHAFT POSITION SENSOR "A" CIRCUIT</b>
------------	--------------	---

<b>DTC</b>	<b>P0339</b>	<b>CRANKSHAFT POSITION SENSOR "A" CIRCUIT INTERMITTENT</b>
------------	--------------	--


## CIRCUIT DESCRIPTION

The crankshaft position sensor (NE signal) consists of a magnet, iron core and pickup coil.

The NE signal plate (crankshaft position sensor plate No. 1) has 34 teeth and is installed on the crankshaft. The NE signal sensor generates 34 signals at every engine revolution. The ECM detects the crankshaft angle and the engine speed based on the NE signals, and the cylinder detection based on the combination of the G2 and NE signals.

DTC No.	DTC Detection Condition	Trouble Area
P0335	No crankshaft position sensor signal to ECM during cranking (2 trip detection logic)	<ul style="list-style-type: none"> <li>• Open or short in crankshaft position sensor circuit</li> <li>• Crankshaft position sensor</li> <li>• Signal plate (crankshaft position sensor plate No. 1)</li> <li>• ECM</li> </ul>
	No crankshaft position sensor signal to ECM with engine speed 600 rpm or more (2 trip detection logic)	
P0339	In condition (a), (b) and (c), when no crankshaft position sensor (NE) signal is input for 0.05 sec. or more. (a) Engine revolution 1,000 rpm or more (b) STA signal is OFF (c) 3 sec. or more has been lapsed after STA signal is switched from ON to OFF.	

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### HINT:

- Perform troubleshooting of DTC P0335 first. If no trouble is found, troubleshoot the engine mechanical systems.
- Read freeze frame data using the hand-held tester or the OBD II scan tool, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

### 1 INSPECT CRANKSHAFT POSITION SENSOR(RESISTANCE)

- (a) Measure the resistance between the terminals.

#### Resistance:

1,630 - 2,740  $\Omega$  at cold

2,065 - 3,225  $\Omega$  at hot

#### NOTICE:

"Cold" and "Hot" on the table express the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).



- (b) Reference:

Inspection using the oscilloscope.

- (1) During cranking or idling, check the waveform between terminals of the E6 ECM connector.

#### Standard: .


Symbols (Terminal No.)	Specified condition
NE+ (E6-25) $\leftrightarrow$ NE- (E6-24)	Correct waveform is as shown
G2+ (E6-27) $\leftrightarrow$ G2- (E6-32)	



NG

**REPLACE CRANKSHAFT POSITION SENSOR**  
(See page 18-5 )

OK

**2 CHECK HARNESS AND CONNECTOR(CRANKSHAFT POSITION SENSOR - ECM)****Wire Harness Side**

Crankshaft Position Sensor Connector

Y

A54386


- (a) Disconnect the crankshaft position sensor connector.
- (b) Disconnect the E6 ECM connector.
- (c) Check the continuity between the wire harness side connectors.

**Standard (Check for open):**

Symbols (Terminal No.)	Specified condition
Crankshaft position sensor (1) ⇔ NE+ (E6-25)	Continuity
Crankshaft position sensor (2) ⇔ NE- (E6-24)	

**Standard (Check for short):**

Symbols (Terminal No.)	Specified condition
Crankshaft position sensor (1) or NE+ (E6-25) ⇔ Body ground	No continuity
Crankshaft position sensor (2) or NE- (E6-24) ⇔ Body ground	



Y

ECM Connector

A54408

NG

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

**3 CHECK SENSOR INSTALLATION(CRANKSHAFT POSITION SENSOR)**

NG

**TIGHTEN SENSOR**

OK

**4 CHECK CRANKSHAFT POSITION SENSOR PLATE NO.1(TEETH OF PLATE)**

- (a) Remove the crankshaft position sensor plate No. 1 (See page 14-107 ).
- (b) Check the teeth of the signal plate.

NG

**REPLACE CRANKSHAFT POSITION SENSOR PLATE NO.1**

OK

**CHECK AND REPLACE ECM (See page 01-35 )**