



REPLACEMENT

1. **WORK FOR PREVENTING GASOLINE FROM SPILLING OUT** (See page 11-1)
2. **REMOVE CHAIN SUB-ASSY** (See page 14-1 19)
3. **REMOVE EXHAUST FRONT PIPE ASSY NO.2** (See page 15-2)
4. **REMOVE MANIFOLD STAY NO.2**
 - (a) Remove the 3 bolts and manifold stay No. 2.
5. **REMOVE EXHAUST MANIFOLD SUB-ASSY LH**
 - (a) Disconnect the A/F sensor connector.
 - (b) Remove the 6 nuts, exhaust manifold and gasket.
6. **DISCONNECT FUEL PIPE SUB-ASSY NO.1** (See page 11-1)
7. **DISCONNECT FUEL PIPE SUB-ASSY NO.2** (See page 11-1)
8. **REMOVE INTAKE MANIFOLD** (See page 14-163)
9. **REMOVE WATER BY-PASS JOINT RR** (See page 14-163)
10. **REMOVE CHAIN VIBRATION DAMPER NO.1**
 - (a) Remove the 2 bolts and chain vibration damper No. 1.



11. REMOVE CAMSHAFT TIMING GEARS AND NO.2 CHAIN (LH BANK)


- (a) While pushing down the chain tensioner No. 3, insert a pin of ϕ 1.0 mm (0.039 in.) into the hole to fix it.



- (b) Hold the hexagonal portion of the camshaft with a wrench, and remove the 2 bolts, camshaft timing gear, camshaft timing gear assembly and timing chain No. 2.

NOTICE:

- Be careful not to damage the cylinder head and valve lifter with the wrench.
- Do not disassemble the camshaft timing gear assembly.




12. REMOVE CHAIN TENSIONER ASSY NO.3

- (a) Remove the bolt and chain tensioner No. 3.

13. REMOVE CAMSHAFTS

NOTICE:


As the thrust clearance of the camshaft is small, the camshaft must be kept level while it is being removed. If the camshaft is not kept level, the portion of the cylinder head which are received the shaft thrust may crack or be damaged, causing the camshaft to seize or break. To avoid this, the following steps should be carried out.




- (a) Using several steps, loosen and remove the 16 bearing cap bolts uniformly in the sequence as shown in the illustration.
- (b) Remove the 8 bearing caps and 2 camshafts.

14. REMOVE CYLINDER HEAD LH

- (a) Remove the bolt and separate the ground cable.




- (b) Using several steps, remove the 2 cylinder head bolts on the cylinder head in the sequence as shown in the illustration.



- (c) Using several steps, loosen the 8 cylinder head bolts on the cylinder head uniformly with a 10 mm bi-hexagon wrench in the sequence as shown in the illustration. Remove the 8 cylinder head bolts and plate washers.

NOTICE:

- Be careful not to drop the plate washers into the cylinder head.
- Cylinder head warpage or cracking could result from removing bolts in incorrect order.



- (d) Lift the cylinder head from the dowels on the cylinder block, and place the cylinder head on wooden blocks on a bench.


NOTICE:

Be careful not to damage the contact surfaces of the cylinder head and cylinder block.

HINT:

If the cylinder head is difficult to lift off, pry between the cylinder head and cylinder block with a screwdriver.

15. REMOVE CYLINDER HEAD GASKET NO.2

**16. INSPECT CYLINDER HEAD SET BOLT**

- (a) Using a vernier caliper, measure the thread outside diameter of the bolt.

Standard outside diameter:


10.85 - 11.00 mm (0.4272 - 0.4331 in.)

Minimum outside diameter:

10.7 mm (0.421 in.)

17. INSTALL CYLINDER HEAD GASKET NO.2

- (a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the cylinder head and cylinder block.




- (b) Apply a continuous bead of the seal packing (diameter 2.5 - 3 mm (0.098 - 0.118 in.)) to a new cylinder head gasket as shown in the illustration.

Seal packing: Part No. 08826-00080 or equivalent

NOTICE:

Install the cylinder head within 3 minutes after applying seal packing. After installing it, cylinder head bolts must be tightened within 15 minutes. Otherwise the seal packing must be removed and reapplied.



- (c) Place the cylinder head gasket on the cylinder block surface with the Lot No. stamp upward.

NOTICE:


- **Be careful of the installation direction.**
- **Place the cylinder head carefully in order to not damage the gasket with the bottom part of the head.**

18. INSTALL CYLINDER HEAD LH

- (a) Place the cylinder head on the cylinder head gasket.
(b) Install the 8 cylinder head bolts.

HINT:

- The cylinder head bolts are tightened in 2 successive steps (steps (3) and (5)).
- If any cylinder head bolt is broken or deformed, replace it.
 - (1) Apply a light coat of engine oil on the threads of the cylinder head bolts.
 - (2) Install the plate washer to the cylinder head bolt.




- (3) Using several steps, tighten each bolt uniformly with a 10 mm bi-hexagon wrench in the sequence as shown in the illustration.

Torque: 36 N·m (367 kgf·cm, 27 ft·lbf)


If any one of the cylinder head bolts does not meet the torque specification, replace the cylinder head bolt.

NOTICE:

Do not drop the washers into the cylinder head.



- (4) Mark the front side of each cylinder head bolt with paint.
 (5) Retighten the cylinder head bolts 180° revolution as shown.
 (6) Check that the painted marks are now at 180° opposite to the engine front.



- (c) Install the 2 cylinder head bolts.
 (1) Apply a light coat of engine oil on the threads of the cylinder head bolts.
 (2) Using several steps, install and tighten the 2 cylinder head bolts uniformly in the sequence as shown in the illustration.

Torque: 30 N·m (306 kgf·cm, 22 ft·lbf)


- (d) Install the ground cable with the bolt.

Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)

19. INSTALL CAMSHAFTS

NOTICE:

As the thrust clearance of the camshaft is small, the camshaft must be kept level while it is being installed. If the camshaft is not kept level, the portion of the cylinder head which are received the shaft thrust may crack or be damaged, causing the camshaft to seize or break. To avoid this, the following steps should be carried out.




- (a) Set the crankshaft position.
 (1) Using the crankshaft pulley set bolt, turn the crankshaft, and set the crankshaft set key into the left horizontal position.


NOTICE:

Having the crankshaft at the wrong angle can cause the piston head and valve head to come into contact with each other when you install the camshaft, causing damage. So always set the crankshaft at the correct angle.


- (b) Apply new engine oil to the thrust portion and journal of the camshafts.



- (c) Place the 2 camshafts onto the cylinder head with the cam lobes of No. 2 cylinder faced each direction as shown in the illustration.



- (d) Install the 8 bearing caps in their proper locations.
(e) Apply a light coat of engine oil on the threads and under the heads of the bearing cap bolts.




- (f) Using several steps, install and tighten the 16 bearing cap bolts uniformly in the sequence as shown in the illustration.


Torque:

9.0 N·m (92 kgf·cm, 80 in.-lbf) for 10 mm (0.39 in.) head
24 N·m (245 kgf·cm, 18 ft.-lbf) for 12 mm (0.47 in.) head


20. INSTALL CHAIN TENSIONER ASSY NO.3

- (a) While pushing in the tensioner, insert a pin of ϕ 1.0 mm (0.039 in.) into the hole to fix it.






- (b) Install the chain tensioner No. 3 with the bolt.
Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)



21. INSTALL CAMSHAFT TIMING GEARS AND NO.2 CHAIN (LH BANK)


- (a) Align the mark links (yellow) with the timing marks (1 dot mark and 2 dot marks) of camshaft timing gears as shown in the illustration.




- (b) Align the timing marks on the camshaft timing gears with the timing marks on the bearing caps, and install the camshaft timing gears with the chain to the LH camshafts.
 (c) Temporarily install the 2 camshaft timing gear bolts.

NOTICE:

Do not push camshaft timing gear assembly to the camshaft forcibly when installing it.




- (d) Hold the hexagonal portion of the camshaft with a wrench, and tighten the 2 bolts.
Torque: 100 N·m (1,020 kgf·cm, 74 ft·lbf)
 (e) Remove the pin from the tensioner No. 3.



22. INSTALL CHAIN VIBRATION DAMPER NO.1

- (a) Install the chain vibration damper No. 1 with the 2 bolts.
Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)

23. INSTALL WATER BY-PASS JOINT RR (See page 14-163)
24. INSTALL INTAKE MANIFOLD (See page 14-163)
25. CONNECT FUEL PIPE SUB-ASSY NO.2 (See page 11-1)
26. CONNECT FUEL PIPE SUB-ASSY NO.1 (See page 11-1)



27. INSTALL EXHAUST MANIFOLD SUB-ASSY LH

- (a) Set a new gasket to the LH cylinder head with the oval shape is facing backward.

NOTICE:

Be careful of the installation direction.

- (b) Install the exhaust manifold with the 6 nuts. Tighten the nuts uniformly in several steps.
Torque: 30 N·m (306 kgf·cm, 22 ft·lbf)
- (c) Connect the A/F sensor connector.

28. INSTALL MANIFOLD STAY NO.2

- (a) Install the manifold stay No. 2 with the 3 bolts.

Torque: 40 N·m (408 kgf·cm, 30 ft·lbf)

29. INSTALL EXHAUST FRONT PIPE ASSY NO.2 (See page 15-2)

30. INSTALL CHAIN SUB-ASSY (See page 14-1 19)

31. CHECK FOR FUEL LEAKS (See page 11-5)

32. CHECK FOR EXHAUST GAS LEAKS

33. INSPECT ENGINE IDLE SPEED (See page 14-1)

SST 09843-18030

34. INSPECT COMPRESSION (See page 14-1)

35. INSPECT CO/HC (See page 14-1)