


## MANUAL UP/DOWN FUNCTION VIA BACK DOOR LOCK KEY CYLINDER DOES NOT OPERATE

### CIRCUIT DESCRIPTION

If the manual UP/DOWN function via the back door lock key cylinder does not operate, the back door lock key cylinder or the wire harness is abnormal.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

#### 1 CHECK BACK DOOR POWER WINDOW OPERATION


- (a) Check that the back door power window operates via the back door power window switch.

NG

ANOTHER PROBLEM (See page 05-1 136)

OK

#### 2 INSPECT TAIL GATE CONTROL SWITCH ASSY



- (a) Disconnect the switch connector.  
(b) Insert the key to the switch.  
(c) Check the continuity between the terminals of the switch connector when turning the key.

**Standard:**

Terminal No.	Operation	Specified Condition
1 ⇔ 3	Turn key to right	Continuity
1 ⇔ 2	Neutral	No continuity
2 ⇔ 3	Turn key to left	Continuity

NG

REPLACE TAIL GATE CONTROL SWITCH ASSY

OK

REPAIR OR REPLACE HARNESS AND CONNECTOR (BACK DOOR ECU ⇔ SWITCH)