

BACK DOOR POWER WINDOW CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

0593M-01

HINT:

Troubleshoot in accordance with the procedures on the following pages.

1	VEHICLE BROUGHT TO WORKSHOP
----------	------------------------------------



2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05-1 122)
----------	--



3	DIAGNOSTIC TROUBLE CODE CHECK (See page 05-1 126)
----------	--

- (a) Check for DTCs and make a note of the code that is output.
- (b) Delete the DTC.
- (c) Check if the DTC will be output once again when the problem symptom is simulated based on the noted code.
 - (1) With an output of the code, proceed to A.
 - (2) Without an output of the code, proceed to B.

A	Go to step 5
----------	---------------------

B

4	PROBLEM SYMPTOMS TABLE (See page 05-1 130)
----------	---



5	PERFORM TROUBLESHOOTING
----------	--------------------------------

- (a) Pre-check (See page [05-1 123](#))
- (b) Terminals of ECU (See page [05-1 128](#))
- (c) Circuit inspection (See pages [05-1 131](#) - [05-1 139](#))



6	ADJUST, REPAIR OR REPLACE
----------	----------------------------------



7	RESET POWER WINDOW MOTOR
----------	---------------------------------

- (a) Turn the ignition switch ON.
- (b) Open the back door glass.
- (c) Push down the back door power window switch until the door glass is fully closed, and hold the switch 1 second more even after the door glass is fully closed.
- (d) Check that the AUTO UP/DOWN function operates completely.



END
