


## FRONT DOOR GLASS WEATHERSTRIP ASSY OUTER LH REPLACEMENT

### HINT:

- The installation is in the reverse order of the removal. However, when there is a special point concerning the installation, it is indicated.
  - On the RH side, use the same procedures as on the LH side.
1. REMOVE POWER WINDOW REGULATOR MASTER SWITCH ASSY (See page 75-15 )
  2. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH (See page 75-15 )
  3. REMOVE FRONT DOOR INSIDE HANDLE BEZEL LH (See page 75-15 )
  4. REMOVE FRONT ARMREST ASSY LH (See page 75-15 )
  5. REMOVE FRONT DOOR TRIM BOARD SUB-ASSY LH (See page 75-15 )
  6. REMOVE FRONT DOOR SERVICE HOLE COVER LH (See page 75-15 )
  7. REMOVE OUTER REAR VIEW MIRROR ASSY LH (See page 75-15 )
  8. REMOVE FRONT DOOR WINDOW FRAME MOULDING REAR LH (See page 76-31 )



### 9. REMOVE FRONT DOOR GLASS WEATHERSTRIP ASSY OUTER LH

- (a) Put protective tape under the glass weatherstrip assy.
- (b) Remove the screw.
- (c) Using a screwdriver or moulding remover, disengage the claw and remove the glass weatherstrip.

### HINT:

Tape the screwdriver tip before use.