

## RADIO BROADCAST CANNOT BE RECEIVED (BAD RECEPTION)

### INSPECTION PROCEDURE

#### 1 CHECK IF RADIO AUTO-SEARCH FUNCTIONS PROPERLY

- (a) Check if the radio auto-search functions properly.  
 (1) Perform the auto-search of the radio and check that it functions normally.  
**Standard: The radio auto-search functions properly.**

OK

CHECK AND REPLACE RADIO RECEIVER ASSY

NG

#### 2 CHECK OPTIONAL COMPONENT

- (a) Check optional component (Sun shade film, telephone antenna etc.).  
 (1) Check whether or not any optional component is installed, such as the sunshade film and the telephone antenna, is installed.  
**Standard: Optional component is installed.**

OK

EFFECT FROM OPTIONAL COMPONENT

NG

#### 3 CHECK ANTENNA FOR NOISE PRODUCTION

- (a) Noise Check with Antenna  
 (1) With the ignition switch in ACC, turn on the radio and choose the AM mode.  
 (2) Place a tip of a screwdriver or the antenna of the antenna assembly w/ holder and check that the noise heard from the speaker.  
**Standard: Noise occurs.**


OK

CHECK AND REPLACE RADIO RECEIVER ASSY

NG

<b>4</b>	<b>INSPECT RADIO RECEIVER ASSY(ANTENNA)</b>
----------	---

- (a) Preparation for Check
  - (1) Remove the antenna plug of the radio receiver assembly.
- (b) Noise Check
  - (1) With the radio receiver assembly connector connected, turn the ignition switch to ACC.
  - (2) Turn on the radio and choose the AM mode.
  - (3) Place a flat-head screwdriver or a metal such as a thin wire on the antenna jack of the radio receiver assembly and check that the noise heard from the speaker.



**Standard: Noise occurs.**

**OK**

**CHECK AND REPLACE RADIO RECEIVER ASSY**

**NG**

**REPLACE ANTENNA CORD SUB-ASSY**