


REPLACEMENT

HINT:

Installation is in the reverse order of the removal. But the installation is indicated only when it has a point.



1. REMOVE ROOF RACK LEG COVER FRONT LH

- (a) Using a screwdriver, disengage the 4 claws and clip, and remove the leg cover.

HINT:

Tap the screwdriver tip before use.

2. REMOVE ROOF RACK LEG COVER FRONT RH

- (a) Using a screwdriver, disengage the 4 claws and clip, and remove the leg cover.

HINT:

Tap the screwdriver tip before use.

3. REMOVE ROOF RACK LEG COVER REAR LH

- (a) Using a screwdriver, disengage the 4 claws and clip, and remove the leg cover.

HINT:

Tap the screwdriver tip before use.

4. REMOVE ROOF RACK LEG COVER REAR RH



- (a) Using a screwdriver, disengage the 4 claws and clip, and remove the leg cover.

HINT:

Tap the screwdriver tip before use.

5. REMOVE ROOF RACK ASSY

- (a) Remove the 4 bolts and the roof rack assy.



6. REMOVE ROOF RACK LEG FRONT LH


- (a) Remove the 2 screws and rack leg.

7. REMOVE ROOF RACK LEG FRONT RH

- (a) Remove the 2 screws and rack leg.

8. REMOVE ROOF RACK BAR JOINT


- (a) Using a torx wrench (T25), remove the 8 screws the roof rack bar joint.

**9. INSTALL ROOF RACK ASSY**

- (a) Using a white gasoline, clean the bolt and thread.
- (b) Apply adhesive to 2 or 3 threads of the bolt end.

Adhesive:

Part No. 08833-00070, THREE BOND 1324 or equivalent



- (c) Install the roof rack assy with the 4 bolts.