



INSPECTION



1. INSPECT GARAGE DOOR OPENER

- (a) Press the switch and check that each LED (red) lights up. Even if only one switch is found not to light up, replace the garage door opener.



2. INSPECT GARAGE DOOR OPENER REGISTRATION AND TRANSMITTING


HINT:

Use the home link tester made by KENT MORE for this test. Because it is necessary to register the code of the hand-held transmitter, the customer's code should be erased. When the inspection is complete, register the customer's code again.

- (a) Check that the code of hand-held transmitter for inspection can be registered.

HINT:

If the code can not be registered, replace the garage door opener.



- (b) Press the switch which inspection code has been registered for and check that LED (green) of the home link tester lights up.

HINT:

If the LED (green) does not light up, replace the garage door opener.