


NAVIGATION ECU REPLACEMENT

670L2-01

HINT:

COMPONENTS: See page 67-2


1. REMOVE TONNEAU COVER RETRACTOR SUB-ASSY(See page 76-42)
2. REMOVE BACK DOOR WEATHERSTRIP(See page 76-42)
3. REMOVE DECK BOARD SUB-ASSY(See page 76-42)
4. REMOVE DECK BOARD ASSY(See page 76-42)
5. REMOVE REAR FLOOR MAT SUPPORT PLATE REAR(See page 76-42)
6. REMOVE DECK FLOOR BOX RH(See page 76-42)
7. REMOVE DECK TRIM COVER REAR(See page 76-42)
8. REMOVE DECK TRIM SIDE BOARD UPR RH(See page 76-42)
9. REMOVE SIDE TRIM BOX ASSY RH(See page 76-42)
10. REMOVE REAR DOOR SCUFF PLATE RH(See page 76-42)
11. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP RH(See page 76-42)

**12. REMOVE DECK TRIM SIDE PANEL ASSY RH**


- (a) Remove the screw and deck trim cover.
- (b) Remove the 3 screws and clip.
- (c) Using a screwdriver, disengage the 6 clips and remove the trim panel.

HINT:


Tape the screwdriver tip before use.

**13. REMOVE NAVIGATION COMPUTER W/BACKET**

- (a) Disconnect the connectors.
- (b) Remove the 3 bolts and navigation computer w/bracket.

**14. REMOVE MULTI-DISPLA Y CONTROLER BRACKET A**

- (a) Remove the 2 screws and multi-display controller bracket A.

**15. REMOVE MULTI-DISPLAY CONTROLLER BRACKET B**

- (a) Remove the 2 screws and multi-display controller bracket B.