


# FRONT NO.1 SPEAKER ASSY REPLACEMENT

67OK9-01


HINT:

COMPONENTS: See page 67-2

1. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH(See page 75-15 )
2. REMOVE FRONT DOOR INSIDE HANDLE BEZEL LH(See page 75-15 )
3. REMOVE FRONT ARMREST ASSY LH(See page 75-15 )
4. REMOVE FRONT DOOR TRIM BOARD SUB-ASSY LH(See page 75-15 )



5. REMOVE FRONT NO.1 SPEAKER ASSY
  - (a) Disconnect the connector.
  - (b) Remove the 4 screws and front No.1 speaker assy.



6. INSTALL FRONT NO.1 SPEAKER ASSY
  - (a) Install the front No.1 speaker assy with the 4 screws.

**NOTICE:**  
Install them in the order shown in the illustration.

  - (b) Connect the connector.