


REPLACEMENT

1. PRECAUTION(See page 60-1)
2. DISCONNECT BATTERY NEGATIVE TERMINAL(See page 60-1)
3. REMOVE FRONT DOOR SCUFF PLATE LH(See page 76-42)
4. REMOVE REAR DOOR SCUFF PLATE LH(See page 76-42)
5. REMOVE FRONT DOOR OPENING TRIM WEATHERSTRIP LH(See page 76-42)
6. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP LH(See page 76-42)
7. REMOVE LAP BELT OUTER ANCHOR COVER(See page 76-42)
8. REMOVE CENTER PILLAR GARNISH LOWER LH(See page 76-42)
9. REMOVE FRONT SEAT OUTER BELT ASSY LH(See page 61-10)



10. REMOVE SIDE AIR BAG SENSOR ASSY LH
 - (a) Remove the 2 nuts and side airbag sensor assy LH.
 - (b) Disconnect the connector from the side airbag sensor assy LH.

11. INSPECT SIDE AIR BAG SENSOR ASSY LH(See page 60-8)
12. INSTALL SIDE AIR BAG SENSOR ASSY LH
 - (a) Connect the side airbag sensor connector.
 - (b) Install the side airbag sensor assy LH with the 2 nuts.
Torque: 17.5 N·m (178 kgf·cm, 13 ft·lbf)

NOTICE:

- Installation of the connector is done with the sensor assembly installed. Make sure the sensor assembly is installed with the specified torque.
 - If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
 - When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
 - After installation, shake the sensor assembly to check that there is no looseness.
13. INSTALL FRONT SEAT OUTER BELT ASSY LH(See page 61-10)
Torque:
Upper bolt: 7.5 N·m (76 kgf·cm, 66 in·lbf)
Lower bolt: 42 N·m (420 kgf·cm, 31 ft·lbf)
 14. INSPECT SRS WARNING LIGHT(See page 05-614)