


POWER SOURCE LOCATION


68045-01



P

133403


Engine Room Relay Block



RELAY

FUSE

A. ACC CUT	1. ALT	140 A	12. STOP	10 A
B. FR FOG	2. HEATER	50 A	13. AC115 INV	15 A
C. ST	3. AIR SUS	50 A	14. FR FOG	15 A
D. IG	4. AM1	50 A	15. -	
E. HEATER	5. TOWING BRK	30 A	16. OBD	7.5 A
F. MG CLT	6. J/B	50 A	17. HEATER No.2	7.5 A
G. AC115 INV	7. BATT CHG	30 A	18. AIR SUS No.2	10 A
H. DEFOG	8. TOWING	40 A	19. SEAT HTR	25 A
I. -	9. -		20. DEFOG	30 A
	10. -		21. MIR HTR	15 A
	11. -			




RELAY

FUSE

A. ABS MTR	1. HEAD LO RH	10 A	13. SHORT Pin	
B. TRC MTR	2. HEAD LO LH	10 A	14. ALT-S	7.5 A
C. ABS SOL	3. HEAD HI RH	10 A	15. -	
D. HEAD	4. HEAD HI LH	10 A	16. HORN	10 A
E. STOP LP	5. EFI No.2	10 A	17. A/F HTR	15 A
F. C/OPN	6. DOME	10 A	18. TRN-HAZ	15 A
G. DOME	7. RADIO No.1	20 A	19. ETCS	10 A
H. EFI	8. ECU-B	10 A	20. EFI	20 A
I. A/F HTR	9. -		21. -	
J. FUEL PUMP	10. ABS MTR	40 A	22. DR/LCK	20 A
	11. AM2	30 A	23. TOWING	30 A
	12. ABS SOL	50 A	24. RADIO No.2	20A
			25. -	

Instrument Panel Junction Block Assy


**RELAY**

- A. HORN
- B. TAIL
- C. POWER
- D. DC SKT

FUSE

1. -		14. PWR OUTLET	15 A
2. IG 1	15 A	15. -	
3. CIG	10 A	16. GAUGE	7.5 A
4. 4WD	20 A	17. P P/SEAT	30 A
5. ECU-IG	10 A	18. -	
6. ACC	7.5 A	19. SRS	10 A
7. -		20. D P/SEAT	30 A
8. RR WSH	15 A	21. SECUR/HORN	10 A
9. TAIL	10 A	22. IGN	10 A
10. FR WIP-WSH	30 A	23. -	
11. -		24. STA	7.5 A
12. -		25. POWER	30A
13. ST No.2	7.5 A		


Engine Room Relay Block No.2



RELAY

- A. BATT CHG
- B. TOWING TAIL

Engine Room Relay Block No.5



RELAY

- A. AIR SUS
- B. -