

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the chart below (Proceed to the page given for that circuit).

DTC No. (See page)	Diagnostic Item	Trouble Area
B1214 (05-1276)	Door system communicatin bus malfunction (+B short)	<ul style="list-style-type: none"> • Theft warning ECU assy (Theft deterrent ECU) • Multiplex network door ECU back (Back door ECU) • Wire harness • Instrument panel junction block assy (Body ECU)
B1215 (05-1276)	Door system communicatin bus malfunction (GND short)	<ul style="list-style-type: none"> • Theft warning ECU assy (Theft deterrent) • Multiplex network door ECU back (Back door ECU) • Wire harness • Instrument panel junction block assy (Body ECU)
B1269 (05-1281)	Theft deterrent ECU communication stop	<ul style="list-style-type: none"> • Theft warning ECU assy (Theft deterrent ECU) • Wire harness
B1287 (05-1285)	Back door ECU communication stop	<ul style="list-style-type: none"> • Multiplex network door ECU back (Back door ECU) • Wire harness