


DTC	36	AIR MIX DAMPER POSITION SENSOR CIRCUIT (DRIVER SIDE)
-----	----	--

CIRCUIT DESCRIPTION

TPDR terminal voltage (V)




This sensor detects the position of the air mix damper and sends the appropriate signals to the A/C amplifier. The position sensor is built into the damper servo sub-assy (air mix damper control servomotor).

HINT:
This DTC is indicated only for limited grade (right/left independent temperature control system).


DTC No.	Detection Item	Trouble Area
36	Short to ground or power source circuit in air mix damper position sensor circuit.	<ul style="list-style-type: none">• Damper servo sub-assy (air mix damper position sensor)• Harness of connector between damper servo sub-assy (air mix damper position sensor) and A/C amplifier• A/C amplifier

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT AIR CONDITIONING AMPLIFIER(TPDR, SG)



- (a) Remove the A/C amplifier with the connectors being connected.
- (b) Turn the ignition switch to ON.
- (c) Change the set temperature to activate the air mix damper, and measure the voltage between terminal TPDR and SG of the A/C amplifier.

Voltage:**MAX. COLD: 3.5 - 4.5 V****MAX. HOT: 0.5 - 1.8 V****HINT:**


As the set temperature increases, the voltage decreases gradually without interruption.

OK

**PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN ON PROBLEM SYMPTOMS TABLE**

NG

2 INSPECT DAMPER SERVO SUB-ASSY



- (a) Remove the damper servo sub-assy.
- (b) Measure resistance between terminal 1 and 2 of the damper servo sub-assy connector.

Resistance: 4.2 - 7.8 kΩ

- (c) While operating damper servo sub-assy as shown in the procedure on page 05-583, measure resistance between terminal 1 and 3 of damper servo sub-assy.



Resistance:

MAX. COLD: 3.4 - 6.2 kΩ

MAX. HOT: 0.8 - 1.6 kΩ

HINT:

As the damper servo sub-assy moves from COLD side to HOT side, the resistance decreases gradually without interruption.



NG

REPLACE DAMPER SERVO SUB-ASSY

OK

3 CHECK HARNESS AND CONNECTOR(BETWEEN AIR MIX DAMPER POSITION SENSOR AND AIR CONDITIONING AMPLIFIER)

- (a) Check for open and short circuit in the harness and the connector between the damper servo sub-assy (air mix damper position sensor) and the A/C amplifier (See page 01-35).

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK DIAGNOSTIC TROUBLE CODE

- (a) Start up the DTC check mode.
- (b) Check that DTC 36 is not output again.

Standard: DTC 36 is not output.

OK**SYSTEM OK****NG****CHECK AND REPLACE AIR CONDITIONING AMPLIFIER**