


REPLACEMENT

HINT:


COMPONENTS: See page 65-7

1. REMOVE RADIATOR GRILLE LOWER (See page 76-2)




2. REMOVE FRONT BUMPER FILLER LH

- (a) Remove the screw and front bumper filler LH.




3. REMOVE LH HEADLAMP ASSY

- (a) Disconnect the connector.
 (b) Remove the bolt, 3 screws and LH headlamp assy.




4. REMOVE HEADLAMP, NO.1 BULB

- (a) Remove the headlamp, No.1 bulb as shown in the illustration.




5. REMOVE HEADLAMP, NO.2 BULB

- (a) Remove the headlamp, No.2 bulb as shown in the illustration.

**6. REMOVE CLEARANCE LAMP BULB**

- (a) Remove the clearance lamp socket and clearance lamp bulb as shown in the illustration.
- (b) Remove the clearance lamp bulb from the clearance lamp socket.

7. REMOVE CLEARANCE LAMP SOCKET**8. REMOVE HOOD TO FR END PANEL SEAL NO.2**

- (a) Remove the hood to front end panel seal No.2 from the headlamp unit assy LH.

9. REMOVE HEADLAMP UNIT ASSY LH**10. HEADLIGHT AIM ONLY (See page [65-10](#))**