



## OVERHAUL




### 1. REMOVE REPAIR SERVICE STARTER KIT

- (a) Remove the nut, and disconnect the lead wire from the repair service starter kit.



- (b) Remove the 2 screws which are used to secure the repair service starter kit to the starter drive housing.  
 (c) Remove the repair service starter kit.  
 (d) Remove the return spring and plunger.



### 2. REMOVE STARTER YOKE ASSY

- (a) Remove the 2 through bolts, and pull out the starter yoke assy together with the commutator end frame assy.

### 3. REMOVE STARTER COMMUTATOR END FRAME ASSY


- (a) Remove the commutator end frame assy from the starter yoke assy.

### 4. REMOVE STARTER ARMATURE PLATE


- (a) Remove the starter armature plate from the starter yoke assy.

### 5. REMOVE STARTER COMMUTATOR END FRAME COVER


- (a) Using a screwdriver, remove the cover.

**6. REMOVE STARTER ARMATURE ASSY**


- (a) Using snap ring pliers, remove the snap ring and plate washer.
- (b) Remove the starter armature assy from commutator end frame assy.

**7. REMOVE PLANETARY GEAR**

- (a) Remove the 3 planetary gears.


**8. REMOVE STARTER CENTER BEARING CLUTCH SUB-ASSY**

- (a) Remove the starter center bearing clutch and drive lever set pin together from the starter drive housing.
- (b) Remove the drive lever set pin from the starter center bearing clutch.

**9. INSPECT STARTER ARMATURE ASSY**


- (a) Check the commutator for open circuit.
  - (1) Using an ohmmeter, check that there is continuity between the segments of the commutator.

If there is no continuity between any segments, replace the armature.




- (b) Check the commutator for ground.
  - (1) Using an ohmmeter, check that there is no continuity between the commutator and armature coil core.

If there is continuity, replace the armature.
- (c) Check the commutator for dirty and burn on surface. If the surface is dirty or burnt, correct it with sandpaper (No.400) or a lathe.




- (d) Using vernier calipers, measure the commutator length.  
**Standard length: 3.1 mm (0.122 in.)**  
**Maximum length: 3.8 mm (0.150 in.)**  
 If the length is greater than maximum, replace the armature.



#### 10. INSPECT STARTER COMMUTATOR END FRAME ASSY

- (a) Using vernier calipers, measure the brush holder length.  
**Standard length: 9.0 mm (0.354 in.)**  
**Maximum length: 4.0 mm (0.158 in.)**  
 If the length is less than minimum, replace the starter commutator end frame assy.



- (b) Check the brush holder.  
 (1) Using an ohmmeter, check that there is no continuity between the positive (+) and negative (-) brush holders.


If there is continuity, repair or replace the starter commutator end frame assy.

#### 11. INSPECT STARTER CENTER BEARING CLUTCH SUB-ASSY

- (a) Inspect the gear teeth of the planetary gear, and the starter center bearing clutch for wear or damage.


If any one of the planetary gear is damaged, replace the planetary gear assembly.

If any one of the gears of the starter center bearing clutch is damaged, replace the clutch.



- (b) Check the clutch pinion gear.  
 (1) Rotate the clutch pinion gear clockwise and check that it turns freely.  
 (2) Try to rotate the clutch pinion gear counterclockwise and check that it locks.


If necessary, replace the center bearing clutch sub-assy.



## 12. INSPECT REPAIR SERVICE STARTER KIT

- (a) Check the plunger.
- (1) Push in the plunger and check that it returns quickly to its original position.


If necessary, replace the repair service starter kit.



- (b) Check the pull-in coil for open circuit.

- (1) Using an ohmmeter, check that there is continuity between terminal 50 and C.


If there is no continuity, replace the repair service starter kit.



- (c) Check whether or not the hold-in coil has an open circuit.


- (1) Using an ohmmeter, check that there is continuity between terminal 50 and the switch body.

If there is no continuity, replace the repair service starter kit.



## 13. INSTALL STARTER CENTER BEARING CLUTCH SUB-ASSY

- (a) Install the drive lever set pin to the starter center bearing clutch.
- (b) Install the starter center bearing clutch and drive lever set pin together to the starter drive housing.




## 14. INSTALL PLANETARY GEAR


- (a) Apply grease to the planetary gears and pin parts of the planetary shaft.
- (b) Install the 3 planetary gears.

## 15. INSTALL STARTER ARMATURE ASSY

- (a) Apply grease to the plate washer and armature shaft.
- (b) Install the armature shaft to the starter commutator end frame assy.



- (c) Using snap ring pliers, install the plate washer and new snap ring.



- (d) Using vernier calipers, measure the snap ring.


**Maximum length: 5.0 mm (0.197 in.)**

- If the length is greater than maximum, replace the new snap ring.

## 16. INSTALL STARTER COMMUTATOR END FRAME COVER


### 17. INSTALL STARTER ARMATURE PLATE

- (a) Insert the starter armature plate to the starter yoke assy.




- (b) Align the keyway of the plate with the key inside the starter yoke, and install the plate.


### 18. INSTALL STARTER COMMUTATOR END FRAME ASSY



- (a) Align the starter-commutator-rubber-end frame with the convex cutout of starter yoke.
- (b) Install starter-commutator-end-frame to starter yoke assy.

**19. INSTALL STARTER YOKE ASSY**


- (a) Align the key of the starter yoke assy with the keyway of starter drive housing.




- (b) Install the starter yoke assy with the 2 through bolts.  
**Torque: 6.0 N·m (61 kgf·cm, 53 in·lbf)**

**20. INSTALL REPAIR SERVICE STARTER KIT**


- (a) Apply grease to the plunger and hook.



- (b) Hang the plunger hook of the repair service starter kit to the drive lever.  
(c) Install the plunger and return spring.



- (d) Install the repair service starter kit with the 2 screws.  
**Torque: 7.5 N·m (76 kgf·cm, 66 in·lbf)**



- (e) Connect the lead wire to the terminal with the nut.  
**Torque: 10 N·m (102 kgf·cm, 7.4 ft·lbf)**