


POWER OUTLET SOCKET ASSY CTR REPLACEMENT

670L5-01

HINT:

COMPONENTS: See page 67-2

1. REMOVE CONSOLE UPPER REAR PANEL SUB-ASSY(See page 71-12)
2. REMOVE CONSOLE PANEL SUB-ASSY UPPER(See page 71-12)
3. REMOVE CONSOLE UPPER PANEL GARNISH NO.1(See page 71-12)
4. REMOVE CONSOLE UPPER PANEL GARNISH NO.2(See page 71-12)
5. REMOVE CONSOLE BOX ASSY REAR(See page 71-12)



6. REMOVE POWER OUTLET SOCKET ASSY CTR
 - (a) Release the 2 fitting claws, remove the power outlet socket assy CTR.