

POWER WINDOW CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

059YM-01

HINT:

Troubleshoot in accordance with the procedures on the following pages.

1	VEHICLE BROUGHT TO WORKSHOP
----------	------------------------------------



2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05-1094)
----------	---



3	PROBLEM SYMPTOMS TABLE (See page 05-1098)
----------	---




4	PERFORM TROUBLESHOOTING
----------	--------------------------------

- (a) Pre-check (See page [05-1095](#))
- (b) Circuit inspection (See pages [05-1099](#) - [05-1116](#))



5	ADJUST, REPAIR OR REPLACE
----------	----------------------------------



6	RESET POWER WINDOW MOTOR
----------	---------------------------------

- (a) If any of the power window switch illuminations is blinking after repair, reset the power window.
 - (1) Turn the ignition switch ON.
 - (2) Open the driver side door glass.
 - (3) Pull up the AUTO switch fully of the power window master switch until the door glass closes.
 - (4) Check that the AUTO UP/DOWN function operates completely.



END
