

DTC	P0351	IGNITION COIL "A" PRIMARY/SECONDARY CIRCUIT
------------	--------------	--

DTC	P0352	IGNITION COIL "B" PRIMARY/SECONDARY CIRCUIT
------------	--------------	--

DTC	P0353	IGNITION COIL "C" PRIMARY/SECONDARY CIRCUIT
------------	--------------	--

DTC	P0354	IGNITION COIL "D" PRIMARY/SECONDARY CIRCUIT
------------	--------------	--

DTC	P0355	IGNITION COIL "E" PRIMARY/SECONDARY CIRCUIT
------------	--------------	--

DTC	P0356	IGNITION COIL "F" PRIMARY/SECONDARY CIRCUIT
------------	--------------	--


CIRCUIT DESCRIPTION

HINT:


- These DTCs indicate a malfunction related to primary circuit.
- If DTC P0351 is displayed, check No.1 ignition coil with igniter circuit.
- If DTC P0352 is displayed, check No.2 ignition coil with igniter circuit.
- If DTC P0353 is displayed, check No.3 ignition coil with igniter circuit.
- If DTC P0354 is displayed, check No.4 ignition coil with igniter circuit.
- If DTC P0355 is displayed, check No.5 ignition coil with igniter circuit.
- If DTC P0356 is displayed, check No.6 ignition coil with igniter circuit.

A Direct Ignition System (DIS) has been adopted. The DIS improves the ignition timing accuracy, reduces high-voltage loss, and enhances the overall reliability of the ignition system by eliminating the distributor. The DIS is a 1-cylinder ignition system which ignites one cylinder with one ignition coil. In the 1-cylinder ignition system, the one spark plug is connected to the end of the secondary winding. High voltage generated in the secondary winding is applied directly to the spark plug. The spark of the spark plug passes from the center electrode to the ground electrode.

The ECM determines the ignition timing and outputs the ignition signals (IGT) for each cylinder. Based on the IGT signals, the power transistors in the igniter cut off the current to the primary coil in the ignition coil is supplied to the spark plug that is connected to the end of the secondary coil. At the same time, the igniter also sends an ignition confirmation signal (IGF) as a fail-safe measure to the ECM.



DTC No.	DTC Detection Condition	Trouble Area
P0351 P0352 P0353 P0354 P0355 P0356	No IGF signal to ECM while engine is running	<ul style="list-style-type: none"> • Ignition system • Open or short in IGF or IGT1 - 6 circuit from ignition coil with igniter to ECM • No.1 - No.6 ignition coil with igniter • ECM



Reference: Inspection using the oscilloscope.
During cranking or idling, check the waveform between terminals IGT1 - IGT6 and E1, and IGF and E1 of the E4 and ECM connectors.

The diagram illustrates the ignition system wiring. Power originates from the Battery, passes through the Ignition Switch (IG2, AM2), and is distributed to the six Ignition Coil Assemblies (I1-I6). Each coil assembly has four terminals (1, 2, 3, 4) and is connected to the ECM via IGT and IGF lines. The ECM is labeled with terminal numbers 8, 24, 9, 10, 11, 12, and 13, each with an 'E4' label. The diagram also shows a Noise Filter and a Driver Side J/B. Wire colors and terminal numbers are indicated throughout the diagram.

INSPECTION PROCEDURE

HINT:

Read freeze frame data using the hand-held tester or the OBD II scan tool, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

1 CHECK SPARK PLUG AND SPARK OF MISFIRING CYLINDER (See page 18-3)

NG



Go to step 4

OK

2 CHECK HARNESS AND CONNECTOR(IGNITION COIL ASSY - ECM (IGF SIGNAL TERMINAL))

Wire Harness Side

Ignition Coil Connector



Y

A54393

- Disconnect the I1, I2, I3, I4, I5 or I6 ignition coil connector.
- Disconnect the ECM E4 connector.
- Check for continuity between the wire harness side connectors.

Standard (Check for open):

Symbols (Terminal No.)	Specified condition
Ignition coil (I1-2) - IGF (E4-24)	Continuity
Ignition coil (I2-2) - IGF (E4-24)	
Ignition coil (I3-2) - IGF (E4-24)	
Ignition coil (I4-2) - IGF (E4-24)	
Ignition coil (I5-2) - IGF (E4-24)	
Ignition coil (I6-2) - IGF (E4-24)	



Standard (Check for short):


Symbols (Terminal No.)	Specified condition
Ignition coil (I1-2) or IGF (E4-24) - Body ground	No continuity
Ignition coil (I2-2) or IGF (E4-24) - Body ground	
Ignition coil (I3-2) or IGF (E4-24) - Body ground	
Ignition coil (I4-2) or IGF (E4-24) - Body ground	
Ignition coil (I5-2) or IGF (E4-24) - Body ground	
Ignition coil (I6-2) or IGF (E4-24) - Body ground	

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



3 INSPECT ECM(IGF VOLTAGE)


- Disconnect the ignition coil connector.
- Turn the ignition switch ON.
- Measure the voltage between the terminals of the E4 ECM connector.

Standard:

Symbols (Terminal No.)	Specified condition
IGF (E4-24) - E1 (E6-1)	4.5 to 5.5 V

NG

CHECK AND REPLACE ECM
(See page 01-35)

OK**REPLACE IGNITION COIL ASSY****4 CHECK HARNESS AND CONNECTOR(IGNITION COIL ASSY - ECM (IGT SIGNAL TERMINAL))****Wire Harness Side****Ignition Coil Connector**

- Disconnect the I1, I2, I3, I4, I5 or I6 ignition coil connector.
- Disconnect the ECM E4 connector.
- Check for continuity between the wire harness side connectors.

Standard (Check for open):


Symbols (Terminal No.)	Specified condition
Ignition coil (I1-3) - IGT1 (E4-8)	Continuity
Ignition coil (I2-3) - IGT2 (E4-9)	
Ignition coil (I3-3) - IGT3 (E4-10)	
Ignition coil (I4-3) - IGT4 (E4-11)	
Ignition coil (I5-3) - IGT5 (E4-12)	
Ignition coil (I6-3) - IGT6 (E4-13)	


Standard (Check for short):

Symbols (Terminal No.)	Specified condition
Ignition coil (I1-3) or IGT1 (E4-8) - Body ground	No continuity
Ignition coil (I2-3) or IGT2 (E4-9) - Body ground	
Ignition coil (I3-3) or IGT3 (E4-10) - Body ground	
Ignition coil (I4-3) or IGT4 (E4-11) - Body ground	
Ignition coil (I5-3) or IGT5 (E4-12) - Body ground	
Ignition coil (I6-3) or IGT6 (E4-13) - Body ground	

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR


OK

5 INSPECT ECM(IGT1, IGT2, IGT3, IGT4, IGT5 OR IGT6 VOLTAGE)

- (a) Measure the voltage between the terminals of the E4 and E6 ECM connectors when the engine is cranked.

Standard:

Symbols (Terminal No.)	Specified condition
IGT1 (E4-8) - E1 (E6-1)	Between more than 0.1 V and less than 4.5 V
IGT2 (E4-9) - E1 (E6-1)	
IGT3 (E4-10) - E1 (E6-1)	
IGT4 (E4-11) - E1 (E6-1)	
IGT5 (E4-12) - E1 (E6-1)	
IGT6 (E4-13) - E1 (E6-1)	

NG**CHECK AND REPLACE ECM**
(See page 01-35)**OK****6 INSPECT ECM(IGT1, IGT2, IGT3, IGT4, IGT5 OR IGT6 VOLTAGE)****Wire Harness Side****Ignition Coil Connector**

- (a) Disconnect the I1, I2, I3, I4, I5 or I6 ignition coil connector.
(b) Measure the voltage between the terminals of the E4 and E6 ECM connectors when the engine is cranked.


Standard:

Symbols (Terminal No.)	Specified condition
IGT1 (E4-8) - E1 (E6-1)	4.5 V or more
IGT2 (E4-9) - E1 (E6-1)	
IGT3 (E4-10) - E1 (E6-1)	
IGT4 (E4-11) - E1 (E6-1)	
IGT5 (E4-12) - E1 (E6-1)	
IGT6 (E4-13) - E1 (E6-1)	

NG**CHECK AND REPLACE ECM**
(See page 01-35)**OK**

7 INSPECT IGNITION COIL ASSY(POWER SOURCE)**Wire Harness Side**

Ignition Coil Connector



Y

A54393


- Disconnect the I1, I2, I3, I4, I5 or I6 ignition coil connector.
- Turn the ignition switch ON position.
- Measure the voltage between the terminal of the wire harness side connector and body ground.

Standard:

Terminal No.	Specified condition
I1-1 - Body ground	9 to 14 V
I2-1 - Body ground	
I3-1 - Body ground	
I4-1 - Body ground	
I5-1 - Body ground	
I6-1 - Body ground	

OK**REPLACE IGNITION COIL ASSY****NG****8 CHECK HARNESS AND CONNECTOR(IGNITION COIL ASSY - IGNITION SWITCH)****Wire Harness Side**

Ignition Coil Connector



Y

A54393


- Disconnect the I1, I2, I3, I4, I5 or I6 ignition coil connector.
- Disconnect the ignition switch connector.
- Check for continuity between the wire harness side connectors.

Standard (Check for open):

Symbols (Terminal No.)	Specified condition
Ignition coil (I1-1) - IG2 (6)	Continuity
Ignition coil (I2-1) - IG2 (6)	
Ignition coil (I3-1) - IG2 (6)	
Ignition coil (I4-1) - IG2 (6)	
Ignition coil (I5-1) - IG2 (6)	
Ignition coil (I6-1) - IG2 (6)	

Standard (Check for short):

Symbols (Terminal No.)	Specified condition
Ignition coil (I1-1) or IG2 (6) - Body ground	No continuity
Ignition coil (I2-1) or IG2 (6) - Body ground	
Ignition coil (I3-1) or IG2 (6) - Body ground	
Ignition coil (I4-1) or IG2 (6) - Body ground	
Ignition coil (I5-1) or IG2 (6) - Body ground	
Ignition coil (I6-1) or IG2 (6) - Body ground	



Ignition Switch Connector

A61075

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****REPLACE IGNITION COIL ASSY**