

SRS WARNING LIGHT CIRCUIT MALFUNCTION (DOES NOT LIGHT UP, WHEN IGNITION SWITCH IS TURNED TO ACC OR ON)

CIRCUIT DESCRIPTION

The SRS warning light is located on the combination meter.

When the SRS is normal, the SRS warning light lights up for approx. 6 seconds after the ignition switch is turned from the LOCK position to ON position, and then turns off automatically.

If there is a malfunction in the SRS, the SRS warning light lights up to inform the driver of the abnormality. When terminal TC and CG of the DLC3 are connected, the DTC is displayed by blinking the SRS warning light.

WIRING DIAGRAM

See page [05-81 1](#).

INSPECTION PROCEDURE

1 CHECK SOURCE VOLTAGE

- (a) Measure the voltage of the battery.

OK:

Voltage: 10 - 14 V

NG

REPAIR OR REPLACE HARNESS BETWEEN BATTERY AND AIRBAG SENSOR ASSY CENTER, AND CHARGING SYSTEM

OK

2 CHECK AIR BAG SENSOR ASSY CENTER

- (a) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
 (b) Disconnect the connector from the airbag sensor assy center.
 (c) Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
 (d) Turn the ignition switch to ON.
 (e) Check SRS warning light light up in the combination meter assy.

OK:


Not SRS warning light light up.

NG

REPLACE AIR BAG SENSOR ASSY CENTER

OK

3 CHECK WIRE HARNESS



- (a) Turn the ignition switch to LOCK.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (c) Disconnect the connector from the combination meter.
- (d) Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- (e) Turn the ignition switch to ON.
- (f) For the connector (on the airbag sensor assy center side) between the airbag sensor assy center and the combination meter, measure the voltage between LA and body ground.

OK:

Voltage: Below 1 V

NG

REPAIR OR REPLACE HARNESS BETWEEN AIRBAG SENSOR ASSY CENTER AND COMBINATION METER ASSY

OK

REPAIR OR REPLACE COMBINATION METER ASSY