

DTC	P0500/21	VEHICLE SPEED SENSOR "A"
------------	-----------------	---------------------------------

DTC	P0503/23	VEHICLE SPEED SENSOR "A" INTERMITTENT/ERRATIC/HIGH
------------	-----------------	---

CIRCUIT DESCRIPTION

See page [05-157](#) .

DTC No.	DTC Detection Condition	Trouble Area
P0500/21 P0503/23	No vehicle speed sensor signal to ECM under following conditions (a) and (b): (2 trip detection logic). (a) Park/neutral position switch is OFF (b) Vehicle is being driven	<ul style="list-style-type: none"> • Combination meter assy • Vehicle speed sensor • Vehicle speed sensor circuit • ECM

WIRING DIAGRAM

See page [05-157](#) .

INSPECTION PROCEDURE

See page [05-157](#) .