

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Power seat does not operate	1. Front power seat switch 2. PWR SEAT fuse 3. Wire harness	72-5 68-1 72
Only slide operation function does not operate	1. Front power seat switch 2. Slide motor 3. Wire harness	72-5 72-5 72
Only front vertical operation function does not operate (Driver seat only)	1. Front power seat switch 2. Front vertical motor 3. Wire harness	72-5 72-5 72
Only lifter operation function does not operate (Driver seat only)	1. Front power seat switch 2. Lifter motor 3. Wire harness	72-5 72-5 72
Only reclining operation function does not operate	1. Front power seat switch 2. Reclining motor 3. Wire harness	72-5 72-5 72
Only lumbar support operation function does not operate (Driver seat only)	1. Power seat switch assy (Lumbar support) 2. Lumbar support adjuster motor 3. Wire harness	72-5 72-5 72