


# TAILLIGHT DOES NOT LIGHT UP

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 CHECK LIGHT

- (a) Check the condition A, B or C, when tail lamp does not light up.


A	All
B	Parking lamp only
C	Combination lamp only

**B** Go to step 5

**C** Go to step 7

**A**

### 2 INSPECT TAIL LAMP RELAY



- (a) Inspect tail lamp relay continuity.


#### Standard:

Condition	Tester connection	Specified condition
Constant	1 - 2	Continuity
Constant	3 - 5	No continuity
Apply B+ between terminal 1 and 2	3 - 5	Continuity

**NG** REPLACE TAIL LAMP RELAY

**OK**

### 3 INSPECT HEADLAMP DIMMER SWITCH ASSY



- (a) Inspect light control switch continuity.

- (1) Check that there is continuity between terminals at each switch position as shown in the chart.

#### Standard:

Switch operation	Tester connection	Specified condition
OFF	-	No continuity
TAIL	14 - 16	Continuity

**NG** REPLACE HEADLAMP DIMMER SWITCH ASSY

**OK**

#### 4 CHECK HARNESS AND CONNECTOR(BETWEEN MULTIPLEX NETWORK BODY ECU AND HEAD LAMP DIMMER SWITCH ASSY)

- (a) Check the continuity between terminal B6-8 (TAIL) of the multiplex network body ECU and the head-lamp dimmer switch assy.

**Standard: There is continuity**

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

#### CHECK AND REPLACE MULTIPLEX NETWORK BODY ECU

#### 5 INSPECT LH HEADLAMP ASSY(PARKING LAMP)

- (a) Check that there is a continuity between terminals of headlamp assy.

**Standard:**

**ON: Continuity**

**OFF: No continuity**

OK

REPLACE LH HEADLAMP ASSY

NG

#### 6 CHECK HARNESS AND CONNECTOR(BETWEEN DRIVER SIDE JUNCTION BLOCK AND LH HEADLAMP ASSY)

- (a) Check the continuity between the terminal parking lamp assy and driver side junction block.

**Standard:**

Item	Tester connection	Specified condition
Parking lamp LH	1 - 1B-9	Continuity
Parking lamp RH	1 - 1B-11	Continuity

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

#### CHECK AND REPLACE DRIVE SIDE JUNCTION BLOCK

#### 7 INSPECT REAR COMBINATION LAMP ASSY LH

- (a) Check that there is a continuity between terminals of rear combination lamp assy.

**Standard:**

**ON: Continuity**

**OFF: No continuity**

OK

REPLACE REAR COMBINATION LAMP ASSY LH

NG

8	CHECK HARNESS AND CONNECTOR(BETWEEN DRIVER SIDE JUNCTION BLOCK AND REAR COMBINATION LAMP ASSY)
---	--

- (a) Check the continuity terminals 4 of the combination lamp and 1F-13 of the driver side junction block.  
**Standard: There is continuity**

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE DRIVER SIDE JUNCTION BLOCK