



TERMINALS OF ECU

w/o Side Airbag:



Terminal No.	Symbol	Terminal Name
A	-	Electrical Connector Check Mechanism
B	-	Electrical Connector Check Mechanism
A32-3	LA	SRS Warning Light
A32-5	IG2	Power Source (SRS Fuse)
A32-7	P2-	Squib (Passenger, 2nd step)
A32-8	P2+	Squib (Passenger, 2nd step)
A32-9	+SR	Front Airbag Sensor RH
A32-10	P+	Squib (Passenger)
A32-11	P-	Squib (Passenger)
A32-12	SIL	Diagnosis
A32-13	D-	Squib (Driver)
A32-14	D+	Squib (Driver)
A32-15	+SL	Front Airbag Sensor LH
A32-16	D2+	Squib (Driver, 2nd step)
A32-17	D2-	Squib (Driver, 2nd step)
A32-19	TC	Diagnosis
A32-20	-SR	Front Airbag sensor LH
A32-23	GSW2	ECM
A32-26	-SL	Front Airbag Sensor LH
A32-27	E1	Ground
A32-28	E2	Ground
A31-1	PL-	Squib (Seat Belt Pretensioner, LH)
A31-2	PL+	Squib (Seat Belt Pretensioner, LH)
A31-3	LSP+	Seat Position Sensor
A31-8	LSP+	Seat Position Sensor
A31-11	LBE+	Seat Belt Buckle Switch LH
A34-5	PR+	Squib (Seat Belt Pretensioner, RH)
A34-6	PR-	Squib (Seat Belt Pretensioner, RH)

w/ Side Airbag:



P

H40533

No.	Symbol	Terminal Name
A	-	Electrical Connector Check Mechanism
B	-	Electrical Connector Check Mechanism
A32-3	LA	SRS Warning Light
A32-5	IG2	Power Source (SRS Fuse)
A32-7	P2-	Squib (Passenger, 2nd step)
A32-8	P2+	Squib (Passenger, 2nd step)
A32-9	+SR	Airbag Front RH Sensor
A32-10	P+	Squib (Passenger)
A32-11	P-	Squib (Passenger)
A32-12	SIL	Diagnosis
A32-13	D-	Squib (Driver)
A32-14	D+	Squib (Driver)
A32-15	+SL	Airbag Sensor Front LH
A32-16	D2+	Squib (Driver, 2nd step)
A32-17	D2-	Squib (Driver, 2nd step)
A32-19	TC	Diagnosis
A32-20	-SR	Airbag Front RH Sensor
A32-23	GSW2	ECM
A32-26	-SL	Airbag Sensor Front LH
A32-27	E1	Ground
A32-28	E2	Ground
A30-1	CSL-	Airbag Sensor Rear LH
A30-3	LSP-	Seat Position Sensor
A30-4	LSP+	Seat Position Sensor
A30-7	PL-	Squib (Seat Belt Pretensioner, LH)
A30-8	PL+	Squib (Seat Belt Pretensioner, LH)
A30-9	ICL+	Squib (Curtain Shield Airbag Assy, LH)
A30-10	ICL-	Squib (Curtain Shield Airbag Assy, LH)
A30-11	SFL-	Squib (Side Airbag Assy, LH)
A30-12	SFL+	Squib (Side Airbag Assy, LH)
A30-13	ESCL	Airbag Sensor Rear LH
A30-14	VUCL	Airbag Sensor Rear LH
A30-15	CSL+	Airbag Sensor Rear LH
A30-16	VUPL	Side Airbag Sensor Assy LH

DIAGNOSTICS - SUPPLEMENTAL RESTRAINT SYSTEM

No.	Symbol	Terminal Name
A30-17	SSL+	Side Airbag Sensor Assy LH
A30-18	ESL	Side Airbag Sensor Assy LH
A30-19	LBE+	Seat Belt Buckle Switch LH
A30-20	SSL-	Side Airbag Sensor Assy LH
A33-4	CSR-	Airbag Sensor Rear RH
A33-5	SFR+	Squib (Side Airbag Assy, RH)
A33-6	SFR-	Squib (Side Airbag Assy, RH)
A33-7	ICR-	Squib (Curtain Shield Airbag Assy, RH)
A33-8	ICR+	Squib (Curtain Shield Airbag Assy, RH)
A33-9	PR+	Squib (Seat Belt Pretensioner, RH)
A33-10	PR-	Squib (Seat Belt Pretensioner, RH)
A33-13	SSR-	Side Airbag Sensor Assy RH
A33-15	ESR	Side Airbag Sensor Assy RH
A33-16	SSR+	Side Airbag Sensor Assy RH
A33-17	VUPR	Side Airbag Sensor Assy RH
A33-18	CSR+	Airbag Sensor Rear RH
A33-19	VUCR	Airbag Sensor Rear RH
A33-20	ESCR	Airbag Sensor Rear RH