


# PRESSING POWER SWITCH DOES NOT START SYSTEM



## WIRING DIAGRAM



I33765

1

INSPECT RADIO RECEIVER ASSY(BU+B, ACC+B, GND)



(a) Check that the continuity between terminals at each condition, as shown in the chart.

Standard:

Tester connection	Condition	Specified condition
GND ⇄ Body ground	Constant	Continuity

(b) Check that the voltage between terminals at each condition, as shown in the chart.

Standard:

Tester connection	Condition	Specified condition
BU+B ⇄ GND	Constant	10 - 14 V
ACC+B ⇄ GND	Ignition switch ACC or ON	10 - 14 V

NG

REPAIR OR  
CONNECTOR

REPLACE HARNESS OR

OK

CHECK AND REPLACE RADIO RECEIVER ASSY