


## ACCELERATOR PEDAL ROD ASSY (1GR-FE) REPLACEMENT

100D1-01



### 1. REMOVE ACCELERATOR PEDAL ROD ASSY

- (a) Disconnect the accelerator pedal connector.
- (b) Remove the 2 nuts and the accelerator pedal assy.

### 2. INSTALL ACCELERATOR PEDAL ROD ASSY

#### NOTICE:

- Avoid physical shock to the accelerator pedal assy.
  - Do not disassemble the accelerator pedal assy.
- (a) Install the accelerator pedal assy with the 2 nuts.  
**Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)**
  - (b) Connect the accelerator pedal connector.