

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Engine does not crank (Does not start)	23.Cranking holding function circuit 24.Starter 25.Starter relay	05-207 19-1 19-1
No initial combustion (Does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05-202 05-215 05-27
No complete combustion (Does not start)	1. Fuel pump control circuit	05-215
Engine cranks normally (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05-178 05-215 14-1
Cold engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05-178 05-215
Hot engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05-178 05-215
High engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05-529 05-202
Low engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05-529 05-215
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit	14-1 05-215
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05-202 05-215
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty	05-215 05-440
Surging (Poor driveability)	1. Fuel pump control circuit	05-215
Engine stalls soon after starting	1. Fuel pump control circuit	05-215
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	05-529 05-27
Unable to refuel/Difficult to refuel	1. ORVR system	