


REAR DOOR GLASS WEATHERSTRIP ASSY OUTER LH REPLACEMENT

7600H-01

HINT:

- The installation is in the reverse order of the removal. However, when there is a special point concerning the installation, it is indicated.
 - On the RH side, use the same procedures as on the LH side.
1. **REMOVE POWER WINDOW REGULATOR SWITCH ASSY REAR (See page 75-27)**
 2. **REMOVE REAR DOOR INSIDE HANDLE BEZEL LH (See page 75-27)**
 3. **REMOVE REAR ARMREST ASSY LH (See page 75-27)**
 4. **REMOVE REAR DOOR TRIM BOARD SUB-ASSY LH (See page 75-39)**
 5. **REMOVE REAR DOOR WINDOW FRAME MOULDING FRONT LH (See page 76-18)**



6. REMOVE REAR DOOR GLASS WEATHERSTRIP OUTER

- (a) Remove the screw.
- (b) Put protective tape under the glass weatherstrip.
- (c) Using a screwdriver or moulding remover, disengage the claw and remove glass weatherstrip.

HINT:

Tape the screwdriver tip before use.