

OUTER REAR VIEW MIRROR ASSY LH

REPLACEMENT


700NT-01

HINT:

- The installation is in the reverse order of the removal. However, when there is a special point concerning the installation, it is indicated.
- On the RH side, use the same procedures as on the LH side.


1. REMOVE FRONT DOOR SERVICE HOLE COVER LH (See page 75-15)

- Remove the front door lower frame bracket garnish LH.
- Remove the front door inside handle bezel LH.
- Remove the front armrest assy LH.
- Remove the front door trim board LH.
- Remove the front door service hole cover LH.



2. REMOVE OUTER REAR VIEW MIRROR ASSY LH

- Disconnect the connector.
- Remove the 3 nuts and mirror.



3. INSTALL OUTER REAR VIEW MIRROR ASSY LH

- Install the mirror with the 3 nuts.
Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)
- Connect the connector.