

B62683

INSPECTION PROCEDURE

1 INSPECT FUSE (ECU-IG)

- (a) Remove the ECU-IG fuse from the instrument panel J/B.
- (b) Check the continuity.


Standard: Continuity

NG

REPLACE FUSE

OK

2 INSPECT IGNITION OR STARTER SWITCH ASSY



- (a) Check the switch continuity.

Standard:

Terminal No.	Switch Position	Specified Condition
-	LOCK	No continuity
2 ⇔ 3	ACC	Continuity
2 ⇔ 3 ⇔ 4 6 ⇔ 7	ON	Continuity
1 ⇔ 2 ⇔ 4 6 ⇔ 7 ⇔ 8	START	Continuity

NG

REPAIR OR REPLACE IGNITION OR STARTER SWITCH ASSY


OK

3 CHECK THEFT WARNING ECU ASSY (POWER SOURCE)

Wire Harness Side

T5

Theft Warning ECU Assy
(Theft Deterrent ECU)



- (a) Disconnect the T5 ECU connector.
- (b) Turn the ignition switch ON.
- (c) Check the voltage between the wire harness side connector and body ground.

Standard:

Symbols (Terminal No.)	Condition	Specified Condition
IG (T5-10) ⇔ Body ground	Ignition switch ON	10 - 14 V

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

CHECK AND REPLACE THEFT WARNING ECU ASSY